

To Order

Ready Ref is manufactured, sold, and serviced directly from our factory in Marietta, Ohio. Order online or call toll-free Monday through Friday, 8:00 a.m. to 5:00 p.m. EDT. We are often available before and after office hours so call us anytime.

Telephone orders placed using a credit card are shipped within 24 hours via USPS Priority Mail. Mail-in orders with a check or money order are also shipped within 24 hours.

Model 1150 (silent).....\$79.00

Model 1155 (audible).....\$89.00

Shipping & Handling.....\$13.00

Ohio residents add 7.25% sales tax

Order online


www.ready-ref.com

or

1-800-223-5395



Grimm Scientific Industries, Inc. TEL: 800-223-5395
P.O. Box 2143 FAX: 740-374-5745
Marietta, OH 45750 EMAIL: grimm@ee.net



READY REF


**The Officials' Standard
for On-Field Timing**



Lacrosse Timers

- ✓ Allows you to concentrate on your responsibilities without distraction
- ✓ Gives teams the fairness of timing intervals permitted by rule and develops a nice even flow to the game
- ✓ Provides silent (Model 1150) or audible notification (Model 1155) at 20 and 120 seconds with warning signal at 100 seconds.

#1150 & 1155 Lacrosse Timers



- ✓ **Small & Lightweight**
3.8" Wide x 2.4" High x 1" Deep
4.7 ounces
- ✓ **9-Volt Battery Included**
10,000-cycle battery life
- ✓ **Microprocessor Circuit**
Accurate to within .001 seconds
- ✓ **Secure 2" Belt Loop**



- ✓ **Rain Case Included**



- ✓ **Lifetime Warranty**
Guaranteed to operate reliably for as long as you own it. Simply return Ready Ref with \$13 for return shipping and we'll repair it free.

Operation



1. Press the rocker switch to the "○" open circle position. Ready Ref will vibrate for five seconds at 20 seconds
2. Press the rocker switch to "●" white dot position. Ready Ref will vibrate at 100 seconds for two seconds then again at 120 seconds for five seconds to signal the conclusion of the time out.
3. The "Reset" push button resets the timer.

Maintenance

- Start each season with a new battery
- Use Rain Case to protect from direct heavy rain
- When wet remove battery cover and battery then allow 24 hours to air dry.

Important: Every time you reconnect the battery, press the rocker switch to "○", and allow Ready Ref to finish one complete timing cycle until the LED cycles off. (Do not press the "Reset" button during this procedure). This will activate the microprocessor's battery saving feature.

Ready Ref Personal Timers

1128	Football – One Pre-Warning
1132	Football – Two Pre-Warnings
1140	NCAA Baseball – Silent
1141	NFHS Baseball - Silent
1145	NCAA Softball – Silent
1146	NFHS Softball - Silent
1150	Lacrosse – Silent
1155	Lacrosse – Buzzer
1190	Universal - Silent
1195	Universal - Buzzer