

READY REF® Wireless Play Clock System

NCAA Official's Guide

Introduction

This reliable system provides the back judge direct control of the two end-zone play clocks. Your belt operated transmitter is similar to the Original Ready Ref Personal Timer used by football officials since 1979 for on-field timing. It provides a discrete vibration signal when the clocks reach zero so your eyes stay on the action. The system also times 60-second time out periods and gives the back judge a vibration signal for the 45-second coaches warning.

Transmitter Operation

Press & Release Rocker Switch to "o" - Sends a signal to start the 25-second count on the two end-zone clocks. When the count reaches zero the transmitter will vibrate for five seconds.

Press & Release Rocker Switch to "●" - Sends a signal to start the 40-second count on the clocks. When the count reaches zero the transmitter will vibrate for five seconds.

Press, Pause & Release Rocker Switch to "●" - Sends a signal to start the 60-second count on the clocks. The transmitter will vibrate for two seconds when the count reaches 45 seconds, then for five seconds when the count reaches 60 seconds.

Press "Reset" Button – Sends a signal to the clocks and resets the entire system to zero.

25-Second Mechanic

1. Back judge wears the transmitter on the belt like the Original Ready Ref
2. When the ball becomes dead press rocker to "o"
3. At the snap press the "Reset" button

40-Second Mechanic

1. On the referee's ready-for-play whistle press rocker to "o"
2. At the snap press the "Reset" button

Time-out Mechanic

1. At the referee's time-out or try signal press the rocker to "●".
2. When the transmitter vibrates at 45 seconds notify the wings.
3. When the transmitter vibrates at 60 seconds notify the referee.

Helpful Hints

- Even if one of the end zone clock signals is disrupted, the transmitter timer gives its vibration signals at the correct times.
- A battery should last four games (*The first indication of a weak battery is the motor stops vibrating*)
- If rain threatens protect the transmitter with the rain case provided.



www.grimmscientific.com

Grimm Scientific Industries, Inc.
PO Box 2143, Marietta, OH 45750
Tel: 800-223-5395
Fax: 740-374-3412